

AquaTru® Application Instructions

- For application on cotton, polyester, poly/cotton blends, Spandex, Lycra®, & woven nylons
- An extra transfer is provided for testing purposes
- Before applying, check your transfers for spelling, color placement, etc.

Washing Instructions: For best results - wash inside out, warm; dry on low.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 275°F

Time: 12-15 Seconds

Pressure: Medium 4-6 (40-60psi)

2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

3. Position Your Transfer & Press

- Place the transfer image side down on the apparel
- Close machine and press for 12-15 seconds

4. Peel Transfer Carrier Hot

- Open machine and peel off the backing in a smooth, even motion.

Tips:

- Do not use a pillow
- For clam heat presses, try using a Transfer Express cover sheet to reduce static buildup.

Resources:

[TransferExpress.com/videos](https://www.transferexpress.com/videos)

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. [TransferExpress.com/webinars](https://www.TransferExpress.com/webinars)

Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

Have a question?

Email us at info@TransferExpress.com

TransferExpress.com
1-800-622-2280

Monday- Friday
8 am - 6 pm ET

info@TransferExpress.com

Join our social community for the latest products, services & tips!



STAHL'S
TRANSFER EXPRESS®