

Peel & Press Letters Application Instructions

- For application on cotton, polyester or poly/cotton blends.
- Before applying, check your transfers that they are correct.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 360° - 370°F

Time: 4 Seconds

Pressure: Med/Firm 6-8 (60-80psi)

2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

3. Peel Letters

- Peel the desired letters off the release paper by peeling from one corner.

4. Position Your Letters & Press

- Place the letters on the apparel and cover with the provided cover sheet
- Close machine and press for 4 seconds

5. Pause & Peel

- Open machine and pause for 3-5 seconds.
- Peel off the cover sheet in a smooth, even motion.

Tips:

- This product can also be applied at 340°F for 8 seconds
- Do not use a pillow

Resources:

TransferExpress.com/videos

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. TransferExpress.com/webinars

Join our social community for the latest products, services & tips!

TransferExpress.com/SocialCommunity



Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

Have a question?

Email us at info@TransferExpress.com

TransferExpress.com
1-800-622-2280

Monday- Friday
8am-10 pm EST

info@TransferExpress.com

