

Puff Application Instructions

For application on cotton, polyester or poly/cotton blends.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 360° - 370°

Time: 5 Seconds

Pressure: Med/Firm 6-8 (60-80psi)

2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

3. Position Your Transfer & Press

- Place the transfer image side down on the apparel
- Close machine and press for 5 seconds

4. Peel Transfer Carrier Hot

- Open machine and peel off the paper backing in a smooth, even motion.

Tips:

- Thread your garment on heat press to apply Puff (apply to a single layer).
- Remove Quick Slip Pad Protector from your press before pressing.
- Do not use a pillow.

Resources:

[TransferExpress.com/videos](https://www.transferexpress.com/videos)
[TransferExpress.com/application-tips](https://www.transferexpress.com/application-tips)

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business.
[TransferExpress.com/webinars](https://www.transferexpress.com/webinars)

Join our social community for the latest products, services & tips!

[TransferExpress.com/SocialCommunity](https://www.transferexpress.com/SocialCommunity)



Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

First time?

Call us...

We will walk you through!

[TransferExpress.com](https://www.transferexpress.com)

1-800-622-2280

[info@TransferExpress.com](mailto:info@transferexpress.com)

Monday- Friday
8am-7pm EST

