CAD-PRINTZ® Wall Graphics

Applies to any smooth surface.

1. Clean Surface

- Always apply graphic to a smooth, clean, dry surface.
- * For larger sizes, it may be easier to have additional help.

2. Remove Graphic

• Carefully remove graphic from paper liner. Avoid adhesive to adhesive contact. If this occurs, gently pull apart.

3. Smooth

• Smooth out any air bubbles by hand during application.* If needed, smooth design with a straight edge tool such as a squeegee or credit card.

4. Save Liner

- Save the paper liner! To transfer to another location, place the graphic on the alossy liner to protect from debris or sticking to other objects.
- * The CAD-PRINTZ ® Wall Graphic is made from a fabric media with a patented adhesive that will never weaken and will not leave sticky residue behind. It can be removed and repositioned over and over.

Resources:

TransferExpress.com/videos TransferExpress.com/application-tips

Helping Your Business Grow

loin us each month for a free online class. to grow your knowledge & skills in heat printing, custom transfers & your business. TransferExpress.com/webinars

Join our social community for the latest products, services & tips!

TransferExpress.com/SocialCommunity











Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers

First time?

Call us... We will walk you through!

TransferExpress.com

1-800-622-2280

Monday- Friday 8am-7pm EST

info@TransferExpress.com

