

CAD-PRINTZ® Window Decals

Printed on a carrier to make application to any window easy.

1. Clean Surface

- Always apply graphic to a smooth, clean, dry surface.

2. Remove Graphic

- Carefully remove graphic from paper liner. Avoid adhesive to adhesive contact. If this occurs, gently pull apart.

3. Position

- Start with one end or corner of design and apply.

4. Smooth

- Smooth design with a straight edge tool such as a squeegee or credit card.

5. Remove

- Start at one corner of the design; slowly remove the transfer tape carefully pulling at a 180 degree angle.

* Your design will arrive masked with a transfer tape on the logo side and is mounted on a paper backing.

Tips:

Moisten surface with soapy water to aid in positioning.

Resources:

[TransferExpress.com/videos](https://www.transferexpress.com/videos)
[TransferExpress.com/application-tips](https://www.transferexpress.com/application-tips)

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. [TransferExpress.com/webinars](https://www.transferexpress.com/webinars)

Join our social community for the latest products, services & tips!

[TransferExpress.com/SocialCommunity](https://www.transferexpress.com/SocialCommunity)



Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

First time?

Call us...

We will walk you through!

[TransferExpress.com](https://www.transferexpress.com)

1-800-622-2280

[info@TransferExpress.com](mailto:info@transferexpress.com)

Monday- Friday
8am-7pm EST

