

# Next Generation Stretch Litho™ Application Instructions

- For application on cotton, polyester or poly/cotton blends.
- An extra transfer is provided for testing purposes
- Before applying, check your transfers for spelling, color placement, etc.

**Washing Instructions:** For best results- Wash inside out, warm; dry on low.

## 1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

**Temperature:** 275°F

**Time:** 11-15 Seconds

**Pressure:** Med/Firm 6-8 (60-80psi)

## 2. Preheat Your Apparel

- Place apparel on platen and press for 3-5 seconds

## 3. Position Your Transfer & Press

- Place the transfer image side down on the apparel
- Close machine and press for 11-15 seconds

## 4. When “COLD” - Peel Transfer Carrier

- Open machine and peel off the backing in a smooth, even motion when cold

\*\*\* Applied Stretch Litho transfers cannot touch other applied Stretch Litho transfers!  
Use caution when stacking finished, 2-sided printed apparel. The transfers will stick together. \*\*\*

### Tips:

- Do not use a pillow
- For clam heat presses, try using a Transfer Express cover sheet to reduce static buildup.
- Do not stack applied Stretch Litho apparel on top of other Stretch Litho apparel

### Resources:

[TransferExpress.com/videos](http://TransferExpress.com/videos)

## Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business.  
[TransferExpress.com/webinars](http://TransferExpress.com/webinars)

Join our social community for the latest products, services & tips!

[TransferExpress.com/SocialCommunity](http://TransferExpress.com/SocialCommunity)



## Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

## Have a question?

Email us at [info@TransferExpress.com](mailto:info@TransferExpress.com)

[TransferExpress.com](http://TransferExpress.com)  
1-800-622-2280

Monday- Friday  
8am-10 pm EST

[info@TransferExpress.com](mailto:info@TransferExpress.com)

